

VIII.2 DESCRIPTION OF FORECAST COMPONENT INTERNAL ARRAYS

This Chapter describes the internal arrays used by the Forecast Component for a Segment.

The arrays P, C and T arrays are used to store information for the Operations that are used in the Segment.

The array TS is used to store information about the time series used by the Segment.

The array D is used to store time series data during the execution of the Segment.

Information is stored in the P, C, T and TS arrays by the Forecast Component Initialization Program (FCINIT) which writes them to the Forecast Component Data Base.

The D array is not stored in a file and used to store data during the execution of the Segment and to provide work space during both initialization and execution.